

XENON LAMP TERMINATOR

DATE: 10/06/2011



- A Health and safety solution for used lamp disposal
- Safely degas pressurized Xenon lamps

With Health and Safety issues becoming ever more important, it has become necessary to design a safe way of rupturing Xenon lamps prior to disposal.

TLS UK have designed and developed the Xenon lamp 'Terminator' to do just that in a few simple steps. The Xenon lamp can now be safely destroyed without danger to the projection staff from either the 10BAR lamp rupture or cuts from loose glass fragments.

To use the Terminator, please follow these instructions:

1. Wrap the used bulb in its protective OSRAM white fleece / or a naked bulb for other brands
2. Fit the Velcro straps around the fleece ensuring that they fasten over the metal end caps and **NOT** the glass neck of the lamp.
3. Operate the latch to open the Terminator lid.
4. Place the fleece covered lamp into the Terminator so that it rests on the support guides.
5. Close the lid.
6. To break the bulb strike the red plunger with a soft mallet, do not use a metal hammer.
7. Open the Terminator lid and remove the broken lamp. All the glass should be contained within the fleece or can be emptied out of the Terminator if a fleece was not used
8. It is now safe to dispose of the lamp.

